

With power supply RMS value measurement Carrying rail housing P13/70





The transducer **SINEAX U553** (Fig. 1) converts a sinusoidal or a distorted AC voltage into a **load independent** DC current or a **load independent** DC voltage proportional to the measured value.

The transducer fulfils all the important requirements and regulations concerning electromagnetic compatibility **EMC** and **Safety** (IEC 1010 resp. EN 61 010). It was developed and is manufactured and tested in strict accordance with the **quality assurance standard** ISO 9001.



Fig. 1. Transducer SINEAX U553 in housing **P13/70** clipped onto a top-hat rail.

#### **Features / Benefits**

 Measuring input: AC voltage, sine or distorted wave forms, RMS value measurement

Measured variable	Measuring range limits
AC voltage	0 20 to 0 690 V

- Measuring output: Unipolar and live-zero output variables
- Measuring principle: Logarithmic method
- AC/DC power supply / Universal
- Standard version as per Germanischer Lloyd

The output amplifier transforms the measuring signal into an impressed DC current output signal A.

The electronic components are supplied with voltage H from the mains supply unit H.




Fig. 2. Block diagram.

#### **Mode of operation**

Input signal U~ is galvanically separated from the mains network using a transformer.

The following mathematical expression is then formed using a root-mean-square value computer

$$U_{eff} = \sqrt{\frac{1}{T}} \int_{0}^{T} u^{2} dt$$

Following filtration by means of an active filter, the transformation properties of the measuring transducer are determined in the succeeding characteristics circuit.

### **Technical data**

#### General

Measured quantity:

Measuring principle:

AC voltage Sine or distorted wave forme RMS value measurement

Logarithmic method

#### Measuring input E 🔶

Nominal frequency f<sub>N</sub>:

Nominal input voltage U<sub>N</sub> (measuring range end value):


Setting:


50/60 or 400 Hz

```
0 ... 20 to 0 ... 690 V
```

Admissible alteration of full-scale

output, variable sensitivity, adjustable with potentiometer Setting range





Own consumption:

≤ 1 VA with input end value

#### Overload capacity:

Measured quantity U <sub>N</sub>	Number of applications	ono	
$1.2 \cdot U_{N}^{-1}$		continuously	
2 · U <sub>N</sub> <sup>1</sup>	10	1 s	10 s

<sup>1</sup> But max. 264 V with power supply from measuring input

## Measuring output A 🕞 🕨

Load-independent			Vc
DC current:	0 1 to 0 20 mA resp. live-zero	Warm-up time	≤ {
Burden voltage:	0.2 1 to 4 20 mA	Influence effects (maxim included in basic error	na):
External resistance:	$R_{ext}$ max. $[k\Omega] = \frac{15 \text{ V}}{I_{av}}$ [mA]	Frequency	40 30
	$I_{AN} = Output current end value$	Crest factor	1 . > 2
Load-independent DC voltage:	0 1 to 0 10 V	Safety	11.7
	resp. live-zero 0.2 1 to 2 10 V	Protection class: Housing protection:	II ( IP
External resistance:	$R_{ext} [k\Omega] \ge \frac{U_{A} [V]}{2 \text{ mA}}$		(te IP (te
Current limit		Contamination level:	2
under overload:	$\leq$ 1.5 · I <sub>AN</sub> at current output Approx. 10 mA at voltage output	Overvoltage category:	-

Voltage limit under ≤ 25 V R<sub>ext</sub> = ∞: Residual ripple in output current: ≤ 0.5% p.p. at setting time 300 ms ≤ 2% p.p. at setting time 50 ms Setting time: 50 ms or 300 ms

#### Power supply $H \rightarrow \bigcirc$

AC/DC power pack (DC or 50/60 Hz)

Table 1: Rated voltages and permissible variations

Rated voltage		Tolerancd		
85 230 V DC / AC		DC – 15 + 33%		
24 60 V DC / AC		AC ± 15%		
Option:	na	connected to the low tension term al side 12 and 13 4 V AC or 24 60 V DC		
Power consumption:	3 \	/A		
Accuracy (acc. to EN 60 688	)			
Reference value:	Οι	Itput end value		
Basic accuracy:	Cla	ass 0.5		
Reference conditions:				
Ambient temperature	15	30 °C		
Input variable	Ra	Rated operating range		
Frequency	f <sub>N</sub> :	± 2 Hz		
Curve shape	Sir	ne-wave		
Crest factor	$\sqrt{2}$	2		
Power supply	In	rated range		
Output burden	Cı. Vo	urrent: 0.5 · R <sub>ext</sub> max. oltage: 2 · R <sub>ext</sub> min.		
Warm-up time	≤ {	5 min.		
Influence effects (maxima included in basic error	a):			
Frequency		400 Hz, ± 0.3% 1000 Hz, ± 0.5%		
Crest factor		2.5 ± 0.2% 2.5 6 ± 0.5%		
Safety				
Protection class:	II (	protection isolated, EN 61 010)		
Housing protection:	(te IP	2 40, housing est wire, EN 60 529) 2 20, terminals est finger, EN 60 529)		
Contamination level:	2			
Overvoltage category:				

Rated insulation voltage		<b>Environmental conditions</b>	
(versus earth):	400 V, input 230 V, power supply	Operating temperature:	– 10 to + 55 °C
	40 V, output	Storage temperature:	– 40 to + 70 °C
Test voltage:	50 Hz, 1 min. acc. to EN 61 010-1	Relative humidity of:	≤ 75%, no dew
	3700 resp. 5550 V, input versus all other circuits as well as outer	Altitude:	2000 m max.
	surface	Indoor use statement!	
	3700 V, power supply versus output as well as outer surface	Ambient tests	
	490 V, output versus outer surface	EN 60 068-2-6:	Vibration
Installation data		Acceleration:	±2g
Mechanical design:	Housing <b>P13/70</b>	Frequency range:	10 150 10 Hz, rate of frequency
Material of housing:	Lexan 940 (polycarbonate), flammability Class V-0 acc. to UL		sweep: 1 octave/minute
	94, self-extinguishing, non-dripping, free of halogen	Number of cycles:	10, in each of the three axes
Mounting:	For rail mounting	EN 60 068-2-27:	Shock
Mounting position:	Any	Acceleration:	$3 \times 50$ g 3 shocks each in 6 directions
Weight:	Approx. 0.3 kg	EN 60 068-2-1/-2/-3:	Cold, dry heat, damp heat
<b>Connecting terminals</b>		IEC 1000-4-2/-3/-4/-5/-6	
Connection element:	Screw-type terminals with indirect	EN 55 011:	Electromagnetic compatibility
	wire pressure	Germanischer Lloyd	
Permissible cross section of the connection leads:	$\leq$ 4.0 mm <sup>2</sup> single wire or	Type approval certificate:	No. 12 259-98 HH
of the connection leads.	$2 \times 2.5 \text{ mm}^2$ fine wire	Ambient category:	С
		Vibrations:	0.7 g

## Table 2: Specification and ordering information


Designation	*Blocking code	No-go with blocking code	Article No./ Feature
SINEAX U553 Order Code 553 - xxxx xx			553 –
Features, Selection			
1. Mechanical design			
Housing P13/70 for rail mounting			4
2. Nominal input frequency			
50/60 Hz			1
400 Hz			3

Continuation see on next page!

NEAX U553     Order Code 553 - xxxx xx       eatures, Selection     .       Measuring range     .       0 100 V     .       0 120 V     .       0 150 V     .       0 250 V     .       0 500 V*     .       Non-standard     [M]	B B B		553 – C
Measuring range       0 100 V       0 110 V       0 120 V       0 150 V       0 250 V       0 500 V*	В		C
0 100 V 0 110 V 0 120 V 0 150 V 0 250 V 0 500 V*	В		С
0 110 V 0 120 V 0 150 V 0 250 V 0 500 V*	В		C
0 120 V 0 150 V 0 250 V 0 500 V*			1
0 150 V 0 250 V 0 500 V*	В		D
0 250 V 0 500 V*			F
0 500 V*	В		J
	С		К
Non-standard [V]	С		L
			Z
0 20 to 0 690 V			
With power supply from measuring input min. 24 V / max. 230 V, see feature 5, lines 3 and 4. * Max. 400 V nominal value of the network against earth (operating voltage acc. to EN 61 010)			
. Output signal			
0 20 mA, R <sub>ext</sub> ≤ 750 Ω			1
4 20 mA, R <sub>ext</sub> ≤ 750 Ω			2
Non-standard [mA]			9
0 1.00 to 0 < 20 0.2 1 to < (4 20)			
0 10 V, R <sub>ext</sub> ≥ 5 kΩ			А
Non-standard [V]			Z
0 1.00 to 0 < 10 0.2 1 to 2 10			
. Power supply			
85 230 V AC/DC			1
24 60 V AC/DC			2
From measuring input ≥ 24 60 V AC		BC	3
From measuring input $\ge 85 \dots 230 \text{ VAC}$		AC	4
Connected to the low tension terminal side 12 and 13 24 V AC / 24 60 V DC			5
. Setting time			
0.3 s			1
50 ms			2
. Test certificate			
Without test certificate			0
Test certificate in German			D
Test certificate in English			E

\*Lines with letter(s) under "no-go" cannot be combined with preceding lines having the same letter under "Blocking code".

### **Electrical connections**



Measuring input
Measuring output
Power supply

#### **Dimensional drawing**




Fig. 6. SINEAX U553 in housing **P13/70** clipped onto a top-hat rail (35 ×15 mm or 35×7.5 mm, acc. to EN 50 022).

#### **Standard accessories**

1 Operating Instructions in three languages: German, French, English



Rely on us.

Camille Bauer Metrawatt AG Aargauerstrasse 7 CH-5610 Wohlen / Switzerland Phone: +41 56 618 21 11 Fax: +41 56 618 21 21 info@cbmag.com www.camillebauer.com